

Outside/Inside Corners | XCI 14

- 1 Verify air/vapor/water resistive barrier is properly installed and a pinhole void free application has been achieved. Report any deficiencies and ensure applicable repairs are conducted prior to Hunter Xci polyiso installation.
- 2 With factory edges exposed, stagger vertical joints at inside and outside corners, interlocking each row of Hunter Xci polyiso. Make sure the corners are straight and plumb. Use either the mechanical or adhesive attachment method previously outlined.
- 3 Fill gaps greater than 1/8" between insulation boards with expanding spray foam or butter edge of board with approved sealant and strike flush. Expanding spray foam may also be applied onto the insulation board edges during installation.

