



HUNTER Xci POLYISOCYANURATE USED AS AN AIR BARRIER INSTALLATION GUIDELINES

HUNTER
CONTINUOUS INSULATION

XCI AB5 Polyiso Insulation Foundation Tie-in

- 1 Verify sheathing has been properly installed. Report any deficiencies and ensure applicable repairs are conducted prior to Hunter Xci polyiso installation.
- 2 Install approved membrane through-wall flashing over the sheathing and apply a minimum 8" up the wall leaving the lower section loose. Incorporate termination bar and approved sealant as required.
- 3 Cut Hunter Xci polyiso with sloped top edge to support flashing. Mechanically or adhesively attach with minimum of one fastener or adhesive dab per linear foot.
- 4 Cut Hunter Xci polyiso at angle to align with previous applied piece and mechanically or adhesively attach following the specified fastening and adhesive patterns above.
- 5 Fill gaps between insulation boards with expanding spray foam or butter edge of board with approved sealant and strike flush. Expanding spray foam may also be applied onto the insulation board edges during installation. Ensure an airtight installation is achieved.
- 6 Apply approved sealant at through-wall flashing gap to ensure an air- and water-tight application is achieved.
- 7 Apply approved adhesive and adhere approved through-wall flashing over sloped edge of Hunter Xci polyiso and onto the brick.

