



# HUNTER Xci POLYISOCYANURATE USED AS AN AIR BARRIER INSTALLATION GUIDELINES

HUNTER  
CONTINUOUS INSULATION

## XCI AB13 Mechanical/Electrical Penetrations

- 1 Verify sheathing has been properly installed. Report any deficiencies and ensure applicable repairs are conducted prior to Hunter Xci polyiso installation.
- 2 Rub the face of the mechanical/electrical box with chalk, place the Hunter Xci polyiso into place and thump the face. The profile of the box will be left on the facing. Cut along the marks and mechanically or adhesively attach the Hunter Xci polyiso as outlined above.
- 3 Fill gaps between insulation boards with expanding spray foam or butter edge of board with approved sealant and strike flush. Expanding spray foam may also be applied onto the insulation board edges during installation. Ensure an airtight installation is achieved.
- 4 Cut FOIL-GRIP 1402 and apply around the penetration. Firmly roll the FOIL-GRIP 1402 with hand roller to strengthen adhesion. Use the "hula skirt" application technique as indicated.
- 5 Verify a continuous air seal at penetration is achieved.

