

Termination at Existing Construction

XCI AB14

- 1 Verify air/vapor/water resistive barrier is properly installed and a pinhole void free application has been achieved. Report any deficiencies and ensure applicable repairs are conducted prior to Hunter Xci application.
- 2 Install Hunter Xci polyiso to the existing using either the mechanical or adhesive attachment method described above. An expansion joint may be required at the abutment, verify with the design professional.
- 3 Fill gaps between insulation boards with expanding spray foam or butter edge of board with approved sealant and strike flush. Expanding spray foam may also be applied onto the insulation board edges during installation. Ensure an airtight installation is achieved.
- 4 Verify a continuous air seal at abutment is achieved.

