



HUNTER Xci POLYISOCYANURATE OVER AIR/VAPOR BARRIER INSTALLATION GUIDELINES

REDUCED FASTENER PENETRATIONS BY 60%

XCI 1

4'x8' Polyiso Insulation Fastener Pattern

Installation of 4' x 8' Hunter Xci Polyiso Over Steel Stud/Standard or FRT Wood Framing with Exterior Gypsum/ Plywood/OSB Sheathing and Air/Vapor/ Water Resistive Barrier

For maximum efficiency, it is ideal to schedule the trades to install the polyiso and the cladding concurrently. In doing so you will reduce the number of fasteners used, reduce the labor, reduce the time of the installation and you will minimize the number of penetrations going through the ci layers.

