

# HUNTER Xci POLYISOCYANURATE OVER AIR/VAPOR BARRIER INSTALLATION GUIDELINES



HUNTER  
CONTINUOUS INSULATION

## HUNTER Xci INSULATION FASTENER SPECIFICATIONS

Insulation Product	Substrate	Screw	Washer	Minimum Penetration of Screw into Substrate
Hunter Xci Foil Hunter Xci Foil (Class A) Hunter Xci CG Hunter Xci CG (Class A) or Hunter Xci 286	Steel Stud, 12 to 20 gauge	#2 Bugle Head Phillips or equivalent size, single thread, with self-tapping point	Minimum 1 3/4" diameter plastic, low profile, compress & hold insulation	Minimum 4 threads through steel stud
	Standard or FRT Wood Studs	#2 Bugle Head Phillips or equivalent size, single thread, sharp-point wood screw		Minimum 1" depth into wood stud
	Wood Sheathing			All the way through sheathing + 3/8"
	Concrete, Concrete Block or Masonry, Option 1	#2 Bugle Head Phillips or equivalent size, high & low hardened cutting threads with pyramid point		Minimum 1 1/2" depth into concrete, concrete block or masonry
	Concrete, Concrete Block or Masonry, Option 2	Plastic screw		

Manufacturer	Products
Rodenhouse, Inc.	Thermal-Grip® CI Washers fitted with Grip-Deck® Screws, Plasti-Grip® PMF Fasteners for concrete/masonry substrates
Wind-Lock®	CI-Lock