



HUNTER Xci PLY, HUNTER Xci PLY (CLASS A) AND HUNTER Xci NB INSTALLATION GUIDELINES

HUNTER
CONTINUOUS INSULATION

CAULKING SEALANT

Sealants may be used to seal Hunter Xci Ply, Hunter Xci Ply (Class A) and Hunter Xci NB insulation board gaps and gaps around penetrations where necessary. During sealant installation, ensure the sealant only bonds to two surfaces. It should not bond to a third surface; if it does, the sealant will not properly perform. Follow sealant manufacturer's suggested application process.

NOTE: Follow application instructions by sealant manufacturer. Do not install one-part sealants into joints exceeding ½" depth.

- Sure Seal Lap Sealant
- CCW-201
- Sure Seal Universal Single-Ply Sealant
- Sikaflex-1A and 2C NS
- NovaLink by Chem Link
- NOVA-FLEX Multipurpose Adhesive Sealant
- Pecora Dynotrol I & II
- Pecora 890, 895
- Sonneborn NP1 & NP2
- GE Silpruf, Silpruf LM
- Others as approved by Hunter Panels

FOAM SEALANT

TVM Fireblock Gun Foam can be used to fill Hunter Xci Ply, Hunter Xci Ply (Class A) and Hunter Xci NB insulation board gaps. This orange-colored foam sealant expands to take the shape of the void, creating an air-tight, and water-resistant bond to the polyiso.

Application surfaces must be free of dust, debris, grease, and other contaminants that will adversely affect the bond. Moistening of the application surface will improve adhesion and cure while resulting in a more dense cellular structure. Installs in minutes and skin formation occurs in 10 minutes.

Full cure time is 12-24 hours depending upon project-specific weather conditions. Contact TVM Building Products directly for distribution locations and other questions relating to their foam sealant. Other similar products as approved by Hunter Panels may also be used.