

4X4 TARGET SUMP FIELD USAGE SHEET




TARGET SUMP®


Slope	Sump	Thickness
1/2" Slope	Q1	0.5" - 1.5"
	Q2	1.5" - 2.5"
	XX1	1.0" - 2.0"
	XX2	2.0" - 3.0"

- No field cuts (Saves 12 field cuts)
- Reduces waste by 75%
- Reduces field labor


R-30	Structural Slope - 2 Layers of 2.6"	
	Sump: Q2	Base: 2.6"
	Total Thickness: 4.1" - 5.1"	




R-30	Full Taper - 2.5" + 2.5" Flat + 0.5" Taper Start	
	Sump: XX2	Base: 2.5"
	Total Thickness: 4.5" - 5.5"	




R-25	Structural Slope - 2 Layers of 2.2"	
	Sump: XX1	Base: 2.2"
	Total Thickness: 3.2" - 4.2"	




R-25	Full Taper - 4.0" Flat + 0.5" Taper Start	
	Sump: Q2	Base: 2.0"
	Total Thickness: 3.5" - 4.5"	




R-20	Structural Slope - 2.0" + 1.5" Flat ISO	
	Sump: Q1	Base: 2.0"
	Total Thickness: 2.5" - 3.5"	




R-20	Full Taper - 3.0" Flat + 0.5" Taper Start	
	Sump: Q2	Base: 1.0"
	Total Thickness: 2.5" - 3.5"	




Min 3.0"	R-17 - Structural Slope and Full Taper	
	Sump: XX2	No Base Needed
	Total Thickness: 2.0" - 3.0"	



Min 2.5"	R-14 - Structural Slope and Full Taper	
	Sump: Q2	No Base Needed
	Total Thickness: 1.5" - 2.5"	



Min 2.0"	R-11.5 - Structural Slope and Full Taper	
	Sump: XX1	No Base Needed
	Total Thickness: 1.0" - 2.0"	



Min 1.5"	R-8.5 - Structural Slope and Full Taper	
	Sump: Q1	No Base Needed
	Total Thickness: 0.5" - 1.5"	

